

SAFETY WARNINGS

Read the instructions carefully and observe all the safety warnings. In the event that the indications regarding the intended use contained in these instructions are not observed, no responsibility for any damage to things or persons can be attributed to L10 Trading.

a) People/product

- This products and its packaging are not toys. Keep out of the reach of children and pets
- Do not swallow and/or chew
- Do not put fingers or objects in the blades
- Do not keep the product unattended near flammable materials (sofas, furniture, fabrics, etc ...).
- If the product overheats very quickly, please disconnect it immediately
- Protect the product from extreme temperatures, direct sunlight, strong vibrations, humidity, damp, flammable gases, vapors or solvents.
- In the event that safe use is no longer possible, deactivate the product and prevent it from being used unintentionally. Safe use is no longer guaranteed if the product:
 - _ shows visible damage
 - _ does not work properly anymore
 - _ has been preserved for prolonged periods under unfavorable environmental conditions
 - _ has been exposed to considerable solicitations due to the transport
- Handle the product with care. Bumps, blows or a fall from small height could damage it.
- Observe also the safety warnings and instructions of the other devices to which the product is connected.
- Don't put the speaker close to the ears: it may cause ear damage
- Attention, LED light:
 - _ do not direct your eyes towards the LED beam

- _ do not look directly or with optical instruments
- Never aim the light beam at a mirror or other reflective surface.
- Never aim the beam at people or animals. This can cause injury to the eyes or skin.
- Never use the product when switching from a cold to a warm environment. The present condensation can, in some cases, ruin the product. Let the product reach the ambient temperature before connecting and using it. This could take several hours.
- Never use the product without supervision
- During operation, the housing is overheated. Allow adequate ventilation. The housing must not be covered!
- Make sure that the cable is not crushed, bent or damaged by sharp edges.
- b) Product containing electrical and electronic components
 - Avoid damaging the components in any case. Damage to them will result in explosion and fire hazards!
 - Never short-circuit the contacts. Do not throw the product into a fire. There is a danger of explosion and fire!
 - Do not use the product when unattended
 - During charging, place the product on a heat-resistant surface. In fact, during this process the accumulation of heat is normal
- c) Other
 - Contact an expert if you have any doubts regarding the operation, safety or connection methods of the product.

CLEANING AND MAINTENANCE

- Never use aggressive detergents, alcohol or other chemical solutions as they can attack the housing or even impair the functionality of the product
- Disconnect the cable before you start cleaning the product
 - Do not immerse the product in water
 - There are no repairable parts inside the battery. Therefore, always avoid opening / dismantling

- A dry, soft and clean cloth is enough for cleaning. Do not press too hard on the housing to avoid scratching it
- Dust can easily be removed using a clean, soft, long-bristle brush

DISPOSAL



Electronic devices are made of recyclable materials and must not be disposed of as household waste. At the end of its service life, the product must be disposed of in compliance with the laws in force in your country. The consumer has the legal obligation (Battery Regulations) to return all used batteries; it is forbidden to dispose of them as household waste. The improper disposal of the appliance constitutes fraudulent conduct and is subject to sanctions by the Public Safety Authority. In this way the legal obligations are respected while contributing to environmental protection.

WARRANTY

All Mojipower products are designed and manufactured to meet high expectations and to provide the best customer experience. Batteries are a consumable good that gradually reduces their autonomy with use. The battery life depends on several factors: the type of use that is made of it, the external temperatures (if very high or very low) and the number of recharge cycles to which they are subjected and how (a partial recharge is worth a total recharge). Normally a battery starts to deteriorate significantly after 6 months of use. The battery consumption, if not anomalous (less than 6 months) is not covered by warranty. In exceptional cases, electronic products may have malfunctions due to manufacturing defects. That is why we offer a full one (1) year warranty (this period is extended by 1 additional year for Italy) from the date

of original retail purchase, which covers defects in materials and workmanship. The replacement warranty is valid only if the original proof of purchase issued to the purchaser, specifying the date of purchase, is presented with the product to be replaced. How does it work? If you believe this product is defective, carefully repack the unit and return the product to your authorized dealer within the warranty period, with the original proof of purchase. Your authorized dealer will replace the product, provided a defect in materials or workmanship is identified. This limited replacement warranty does not apply in cases of abuse or misuse of the product, use contrary to the Mojipower instructions, ordinary wear and tear, incorrect connection, force majeure or unauthorized repair. Any lawsuit for breach of this limited warranty shall be commenced, if at all, within one (1) year of the date that the claim accrues. Mojipower shall not be liable for special, indirect, incidental or consequential damages resulting from the use or the inability to use this product, regardless of the legal theory on which the claim is based. negligence and in the event that the product has been used for purposes other than those for which it was designed. Damages caused by accidents or force majeure events such as fires, floods, earthquakes, wars, vandalism or theft are not covered by warranty. This warranty gives you specific legal rights, and you may have other rights, which vary from country to country. This warranty does not restrict the rights of the consumer mandated under applicable laws. This product shall not be treated as household waste. Instead it shall be handed over to the applicable collection point for the recycling of electrical and electronic equipment. The assistance on the product can be done by contacting directly the point of sale where the purchase was made or by sending an email to info@l10brand.com. Sending to the Service Center does not necessarily imply free repair under warranty. Upon receipt of the product, the Service Center reserves the right to ascertain the validity of the warranty.

BATTERY 2600mAh COMPLIANT USE

The product is protected against overload and short circuit. Contact with damp places, such as bathrooms, should be avoided. For safety and authorization reasons (CE) the product must not be transformed and / or modified. In the event that it is used for purposes other than those previously described, it could be damaged. Furthermore, improper use may cause hazards such as short circuits, fires, electric shocks, etc. Deliver the product to other people only with the instructions for its use. The product complies with national and European legal requirements.

CONTENTS

- 1X Battery
- 1X USB/micro USB cable
- 1X User manual

SPECIFICATIONS

Capacity: 2600mAh
Output: 5V/1A
Input: 5V/1A
Charging cycle: >500
Operating temperature: -10°C - 38°C

HOW TO USE

Make sure that the connected power of the mobile device matches that of the product (see technical data)

a) How to charge the battery

1. Using a micro USB/USB cable (included in the package), connect the product to the USB port of a computer or AC adapter from a power outlet (maximum 2A support). Once connected correctly, the product will start charging.
2. As the battery recharges, a red LED light (located in the USB

- port*) start to flash
 3. When the battery is fully charged, the light stays set
 4. When the product is charged, disconnect the cable
- b) How to charge the devices
1. Insert the USB end of a cable into the battery
 2. Insert the other end of the cable into the device to be recharged
 3. A blue LED light (located in the USB port*) turns on
 4. When the battery runs out of power, the light starts to flash for a few seconds and it turns off
 5. Disconnect the cable



light located in the USB port*

*In some models, it may be possible that the light is not so visible. To make it more visible, please put your hands on the USB port to make it dark.

BATTERY 4500mAh COMPLIANT USE

The product is suitable for charging the battery of all smartphones. The product is protected against overload and short circuit. Contact with damp places, such as bathrooms, should be avoided. For safety and authorization reasons (CE) the product must not be transformed and / or modified. In the event that it is used for purposes other than those previously described, it could be damaged. Furthermore, improper use may cause hazards such as short circuits, fires, electric shocks, etc. Deliver the product to other people only with the instructions for its use. The product complies with national and European legal requirements.

CONTENTS

- 1X Battery
- 1X USB/micro USB cable
- 1X User manual

SPECIFICATIONS

Capacity: 4500mAh
Output: 5V/2A
Input: 5V/2A
Charging cycle: >500
Operating temperature: -10°C - 38°C

HOW TO USE

Make sure that the connected power of the mobile device matches that of the product (see technical data)

a) How to charge the battery

1. Using a micro USB/USB cable (included in the package), connect the product to the USB port of a computer or AC adapter from a power outlet (maximum 2A support). Once connected correctly, the product will start charging.
 2. As the battery recharges, a red LED light (located in the USB port*) start to flash
 3. When the battery is fully charged, the light stays set
 4. When the product is charged, disconnect the cable
- b) How to charge the devices
1. Insert the USB end of a cable into the battery
 2. Insert the other end of the cable into the device to be recharged
 3. A blue LED light (located in the USB port*) turns on
 4. When the battery runs out of power, the light starts to flash for a few seconds and it turns off
 5. Disconnect the cable



light located in the USB port*

*In some models, it may be possible that the light is not so visible. To make it more visible, please put your hands on the USB port to make it dark.

BATTERY 5200mAh COMPLIANT USE

The product is suitable for charging the battery of all smartphones. The product is protected against overload and short circuit. Contact with damp places, such as bathrooms, should be avoided. For safety and authorization reasons (CE) the product must not be transformed and / or modified. In the event that it is used for purposes other than those previously described, it could be damaged. Furthermore, improper use may cause hazards such as short circuits, fires, electric shocks, etc. Deliver the product to other people only with the instructions for its use. The product complies with national and European legal requirements.

CONTENTS

- 1X Battery
- 1X USB/micro USB cable
- 1X User manual

SPECIFICATIONS

Capacity: 5200mAh
Output: 5V/1A
Input: 5V/1A
Charging cycle: >500
Operating temperature: -10°C - 38°C

HOW TO USE



Make sure that the connected power of the mobile device matches that of the product (see technical data)

a) How to charge the battery

1. Using a micro USB/USB cable (included in the package), connect the product to the USB port of a computer or AC adapter from a power outlet (maximum 2A supported). Once connected correctly, the product will start charging
 2. As the product charges, the wireless indicator turns green, the charge level LED indicators start to flash
 3. The product is charged when all 4 LEDs are on permanently
 4. When the product is charged, disconnect the cable
- b) How to charge the devices
1. Press the On/Off button to start the battery
 2. Insert the USB end of a cable into the battery
 3. Insert the other end of the cable into the device to be recharged
 4. Monitor the charging process. Disconnect the cable from the product and the device as soon as the charging is complete



led lights

on/off button

BLUETOOTH SPEAKER CONTENTS

- 1X Bluetooth speaker
- 1X USB/micro USB cable
- 1X AUX audio cable
- 1X User manual


SPECIFICATIONS

Speaker: D27 mm 4 Ω 2W
Playing time: up to 3 hours
Charging time: 1.5 hours
Bluetooth version: 4.2
Bluetooth distance: up to 10 meters
Lithium Polymer battery input: 230mAh (DC5V)
SNR: ≥85±3db
Frequency Response: 130HZ-20KHZ

HOW TO USE

a) Playing music with a Bluetooth connection

1. Switch on the speaker sliding the on/off button located in the back of the speaker
2. A blue LED light will turn on
3. After a few seconds a red and blue light will start to flash, indicating that the Bluetooth is on and ready to be paired
4. Turn on the Bluetooth on your device, search for "mojispeaker" and select it (if you are prompted to enter a password to complete pairing, enter 0000 and the speaker will connect to your device). Once the pairing is done, the speaker will connect to the last device automatically.
5. You can play, stop or pause the music and control the volume just from your device
6. To power off the speaker, slide the on/off button



- b) *Playing music with an AUX audio cable*
1. Plug the provided AUX audio cable into the speaker and then plug the other end into your device
 2. Now a blue LED light turns on and the speaker is ready to use
- c) *How to charge the speaker*
1. Using the USB/micro USB cable (included in the package) connect the speaker with a USB port of a computer or a wall adapter
 2. The LED light of the speaker flashes in red while charging
 3. When the speaker is fully charged, the light turns off

WIRELESS CHARGING PAD COMPLIANT USE

The product is suitable for charging the battery of all smartphones with Qi wireless charging. The product is protected against overload and short circuit. Contact with damp places, such as bathrooms, should be avoided. For safety and authorization reasons (CE) the product must not be transformed and / or modified. In the event that it is used for purposes other than those previously described, it could be damaged. Furthermore, improper use may cause hazards such as short circuits, fires, electric shocks, etc. Deliver the product to other people only with the instructions for its use. The product complies with national and European legal requirements.

CONTENTS

- 1X Wireless charging pad
- 1X USB/micro USB charging cable
- 1X User manual

SPECIFICATIONS

Input: AC-DC 5V/1A
Output: 5V/1A
Power: 5W
Conversion efficiency: >70%
Launch distance: 4-8 mm
Product compatibility: All Qi compatible devices (iOS, Android, Windows Phone)

HOW TO USE

1. Using a USB/micro USB cable (included in the package), connect the product to an AC adapter from a power outlet
2. A red LED light turns on (the product is ready)
3. Place the device with Qi wireless charging above the charging pad, in the centre. A blue LED light indicates that the device is charging. (If the device is not placed properly in the charging area, or the device is not supported, a blue light starts to blink)
4. When the device is fully charged, the blue light turns red

MULTI CABLE CONTENTS


- 1X Multi cable
- 1X user manual

SPECIFICATIONS

the cables are suitable only for charging
4 cables in 1: 1X USB, 1X Type-C, 1X Micro USB, 1X Lightning
Rated input voltage: DC5V±0.05
Rated input current: 0A-2.1A

HOW TO USE

1. Plug the Lightning, the micro USB or the Type-C cable into your device
2. Plug the USB cable into a USB port of a computer or battery or a wall adapter to charge your device.



CABLE PROTECTOR CONTENTS


- 1X Cable protector
- 1X User manual

SPECIFICATIONS

Mojipower cable protectors are a fun way to decorate and protect your cable* from breakage while plugged in.
**It fits most standard cables*

HOW TO USE

1. Insert the cable into the split opening
2. Slide the cable protector into end of the cable (where the connector is) and secure it



USB FLASH DRIVE CONTENTS

- 1X USB flash drive
- 1X user manual

SPECIFICATIONS

Features: Plug & play (No software is required to install the USB flash drive)
Capacity: 16GB
Speed: write 4-6 MB/s | read 10-13 MB/s
Compatibility: Windows, Mac, Linux Kernel from 2.4.0+. (It is recommended to perform the last update for your Windows, MacOS or Linux before installation)

HOW TO USE

1. Insert the USB flash drive into a USB port of your computer. The operating system will automatically recognize the USB flash drive and install the driver.
2. A message may appear indicating that the device is operating at a slower speed. This happens when you use a

USB 1.1 instead of a USB 2.0 connection. You can ignore this message.
3. Do you want to disconnect the USB flash drive? If you pull it out of the USB port immediately, data may be lost. See below for the safe way:

Windows

In the System toolbar you will find an icon "safely remove hardware". Click on the USB flash drive you want to remove and the connection will be disconnected. Now you can safely remove the USB flash drive from the USB port.

MacOS

To disconnect, drag the flash drive icon to the trash. Now you can safely remove the USB flash drive from the USB port.

AIRPODS CASE CONTENTS

- 1X AirPods case
- 1X String
- 1X user manual

**Please note: Apple AirPods are not included*

SPECIFICATIONS

The wireless charge may not be supported while using this case.
Made of a shock resistant and non-slip grip PVC material to protect your AirPods from dust, shock and scratches.
Designed and manufactured to provide a snug fit for your AirPods case.
Small opening at the bottom for easy cable access for charging.
Comes with a small string so you can conveniently hook it to your bag or key chain.
Compatible with 1st & 2nd GEN Apple AirPods only.

HOW TO INSTALL

1. Open the cap of the case and insert the body of the case first
2. Gently push the AirPods down and the body of the case up until it fits
3. Align the front of the cap
4. Press down firmly to perfectly align the cap as well

HOW TO REMOVE

1. Plug a Lightning cable into your AirPods case
 2. Pull the case down off of your AirPods while pushing the Lightning cable through
- Warning: Do not remove the protective case by pulling the airpods cap.**

3. Press the cap until it clicks.



HAND SANITIZER BOTTLE CONTENTS

- 1X Empty sanitizer bottle with snap-hook
- 1X User manual

SPECIFICATIONS

Capacity: 30ml

HOW TO FILL THE BOTTLE

1. Twist off the white cap
2. Fill the bottle with any sanitizing liquid.



HOW TO USE THE PRODUCT

1. Open the cap
2. Squeeze gently the bottle

MOJIPOWER®

Mojipower is a brand trademark of:
L10 Srl (Italy)